
DOME LIGHT, RECTANGULAR

ECVDMLTST2



INSTALLATION:

- 1. Using the 2 holes in the Dome Light body as a template, mark and drill holes.
- 2. Mount the Dome Light using the (2) supplied mounting screws.

Technical Support: 1-800-338-7337

WIRING:

- 1. Connect the SoundOff Signal Dome Light's black wire to the vehicle's ground (-) wire.
- 2. Connect the SoundOff Signal Dome Light's red wire to the vehicle's positive (+) wire.
- 3. Connect the SoundOff Signal Dome Light's white wire (as applicable) to the vehicle's door switch wire.

TECHNICAL SPECIFICA- TIONS	
Overall Dimensions:	7.03"L x 3.28"W x 0.74"H
Input Voltage Range:	10 - 30 Vdc
Current Consump- tion:	<0.65 amps
Operating Tempera- ture:	-40° to +65° C
# of LEDs:	15 LEDs



Important Information: —

• DO NOT install this product or route any wires in the Air Bag Deployment Zone. Refer to your vehicle Owner's Manual for the location of any air bag deployment zones.



To review our Limited Warranty Statement & Return Policy for this or any SoundOff Signal product please visit our website at www.soundoffsignal.com and select the "Warranty & Returns" link along the left column of our home page. If you have questions regarding this product please contact Technical Services, Monday - Friday, 8 am to 5 pm at 1.800.338.7337, press #4 to skip the automated message. Questions or comments that do not require immediate attention may be emailed to techsupport@soundoffsignal.com.