

DOMELIGHT, RECTANGULAR

ECVDMLTST4



INSTALLATION:

1. Using two holes on each end of the Dome Light body as a template, mark and drill the holes.
2. Make electrical connections (see WIRING at right).
3. Mount the Dome Light using the 2 supplied mounting screws.
4. DO NOT OVERTIGHTEN SCREWS.

WIRING:

1. Connect the Dome Light's white wire to the vehicle's ground (-) wire.
2. Connect the Dome Light's black wire to the vehicle's positive (+) wire.

TECHNICAL SPECIFICATIONS

Overall Dimensions:	5.83"L x 2.80"W x 0.77"H
Input Voltage Range:	9-16 Vdc
Current Consumption:	<0.3 amps
Operating Temperature:	-40° to +65° C
# of LEDs:	15

WARNING

This product contains high intensity LED devices. To prevent eye damage, DO NOT stare into the light beam at close range.

Important Information:

- DO NOT install this product or route any wires in the Air Bag Deployment Zone. Refer to your vehicle Owner's Manual for the location of any air bag deployment zones.



To review our Limited Warranty Statement & Return Policy for this or any SoundOff Signal product please visit our website at www.soundoffsignal.com and select the "Warranty & Returns" link along the left column of our home page. If you have questions regarding this product please contact Technical Services, Monday - Friday, 8 am to 5 pm at 1.800.338.7337, press #4 to skip the automated message. Questions or comments that do not require immediate attention may be emailed to techsupport@soundoffsignal.com.

1.800.338.7337. / www.soundoffsignal.com / Thank you for trusting us with your safety!