


2025 FORD POLICE INTERCEPTOR UTILITY UNDER MIRROR BRACKET KITS

PMP2BKUMB8-D -- Driver Side
PMP2BKUMB8-P -- Passenger Side



WARNING

- HIGH CURRENT interconnects must be properly terminated. Poor crimp quality can cause heat build-up and fire. Follow crimp connector manufacturer instructions.
- DO NOT install this product or route any wires in the Air Bag Deployment Zone. Refer to vehicle Owner's Manual for deployment zones.
- Do NOT use system to disconnect headlights, brake lights or other safety equipment.
- Unit may become hot to touch during normal operation.
- Failure to properly install connectors, fuses or wiring may cause vehicle failure or fire.
- Installation must only be performed by trained technician. Installer must determine vehicle wiring configuration and proper integration of system.
- Use proper wire gauge. All power wires connecting to positive (+) or negative (-) battery terminal or local chassis ground (-) must be sized to supply at least 125% of max. current and properly fused at power source.
- Install protective grommets when routing wire through firewall or metal.

INTRODUCTION.....	2
COMPONENTS	2
INSTALLATION INSTRUCTIONS	2
INSTALLATION IMAGES	3

WARNING

ROUTE WIRES ONLY IN LOCATIONS THAT ARE NOT SUBJECTED TO POTENTIAL WEAR. MAKE SURE TO AVOID ROUTING WIRES IN THE DEPLOYMENT AREA OF YOUR AIR BAG. REFER TO YOUR VEHICLE'S OWNER'S MANUAL FOR AIRBAG DEPLOYMENT ZONES.

**SoundOff
Signal** 

1.800.338.7337 / www.soundoffsignal.com

NOTICE:

Installers and users must comply with all applicable federal, state and local laws regarding use and installation of warning devices. Improper use or installation may void warranty coverage. To review our Limited Warranty Statement & Return Policy for this or any SoundOff Signal product, visit our website at www.soundoffsignal.com/tech-services/returns/. If you have questions regarding this product, contact **Technical Services**, Monday - Friday, 8 a.m. to 5 p.m. ET at 1.800.338.7337 (press #4). Questions or comments that do not require immediate attention may be emailed to techservices@soundoffsignal.com.

ENHANCING SAFETY THROUGH INNOVATION

PMP2BKUMB8-X 1024 REV B

Thank you for purchasing the 2025 Ford Police Interceptor Utility under mirror bracket kit. The Ford PIU under mirror bracket is compatible with the Intersector Surface Mount Light and the mpower® Fascia Light.

- Available in Single, Dual, or Tricolor
- Allows color to be set to flash or steady-burn
- Multiple housing colors available

- 3" and 4", Stud Mount and Quick Mount Options available
- Collaboration with Dow Corning® to develop Clear-Duty™ optical design
- Greater resistance to gravel pitting, scratching, or cracking
- Improved sealing to prevent water from entering light

CONTAINS			
ITEM #	COMPONENT	PMP2BKUMB8-D QTY.	PMP2BKUMB8-P QTY.
1	SMALL SUV UNDER MIRROR BRACKET - DRIVER	1	0
2	SMALL SUV UNDER MIRROR BRACKET - PASSENGER	0	1
3	#8 X.50 SM TRUSSHEAD PHILLIPS	2	2
4	THIN GASKET MATERIAL (6")	1	1
5	PRODUCT WARNING CARD	1	1
6	INSTALLATION INSTRUCTION SHEET(S)	1	1
7	PRODUCT WARNING CARD	1	1
8	CA PROP 65 LABEL	1	1

1. Take the thin gasket provided in the hardware kit and apply to the edge of the bracket that contacts the paint on the vehicle. Once applied to both sides of the bracket, trim the excess gasket off (shown in **FIG. 1**).

2. Take the bracket and put it into the correct position on the vehicle, then using the screw hole in the bracket as a guide (shown in **FIG 2.**), drill a hole for the stainless screw with a 7/64" drill bit.

3. Install provided stainless screws through bracket into mirror housing. Tighten until screw is snug.

4. Now remove the mirror housing from vehicle according to the manufacturer specs.
5. Once mirror is removed, drill another hole for the second stainless screw with a 7/64" drill bit using the screw hole located on the bottom of the bracket.
6. Install the second stainless screw into the newly drilled hole on the bottom side of the bracket (shown in **FIG. 3**). Tighten until screw is snug.
7. Mount light onto bracket with hardware provided with the light and run wires into mirror. (shown in **FIG. 4**). A hole may need to be drilled to create a path for the wires.
8. Re-install the mirror back onto the vehicle and tighten to manufacturer specs.

